

We strive to ensure that our products are of the highest quality and free of manufacturing defects or missing parts. However, if you have any problems with your new product

DO NOT RETURN IT TO THE STORE

please contact us toll free at:

1 (800) 835-7665

FAX: 1 (904) 824-8233

customerexperience@hj-scott.com

Or write to:

Cue&Case A Global Division of Escalade Sports
Customer Service Department
190 Cumberland Park Drive
St. Augustine, FL 32095

Please visit our website at:


www.cueandcase.com

When contacting Cue&Case please have your model number, proof of purchase (sales reciept stating you are original owner), date code (if applicable) and part number if requesting a replacement part. These numbers are located on the product, packaging, and this owners manual.

Your Model	Number HJAR8
Date Code	2 - HJAR8 - 1018 - WJ
Purchase D	ate

PLEASE RETAIN THIS INSTRUCTION MANUAL FOR FUTURE REFERENCE

IMPORTANT! READ EACH STEP IN THIS MANUAL BEFORE YOU BEGIN THE ASSEMBLY.



TWO ADULTS ARE REQUIRED TO ASSEMBLE THIS ICE RAPTOR 8FT HOCKEY TABLE

Tools Required:

T1 - Wrench (Included)
Phillips Screwdriver
Furniture Polish and Cloth

Assembly Tips


Make sure you understand the following tips before you begin to assemble your hockey table.

- 1. Start all bolts by hand before tightening.
- 2. Some drawings or images in this manual may not look exactly like your product. Please read and understand the text before starting each assembly step.




READ AND FOLLOW ALL ASSEMBLY, OPERATION, AND SAFETY INSTRUCTIONS CAREFULLY. AT LEAST TWO ADULTS ARE NEEDED TO PUT THIS HOCKEY TABLE TOGETHER.

HARDWARE IDENTIFIER (To Scale)







H1 - 8mm x 57mm Hex Bolt (12 pcs)

H2 - 8mm x 19mm Flat Washer (12 pcs)


H3 - 6mm x 50mm Hex Bolt (8 pcs)



H4 - 6mm x 19mm Flat Washer (16 pcs)



H5 - Barrel Nut (8 pcs)



H6 - 6mm x 25mm Hex Bolt (8 pcs)



H7 - 3mm x 15mm Phillips Washer Head Screw (4 pcs)



T1 - Wrench (1 pc)

ACCESSORY IDENTIFIER (Not to Scale)



A1 - Striker (2 pcs)




A2 - Puck (2 pcs)




A3 - Felt Pad (2 pcs)

NOTE: A3 Felt Pads may already be attached to **A1** Strikers.


PARTS IDENTIFIER (Not to Scale)



P1 - Hockey Table Cabinet (1 pc)




P2 - Right Leg (2 pcs)




P3 - Left Leg (2 pcs)



P4 - End Leg Panel (2 pcs)



P5 - Side Leg Panel (2 pcs)



P6 - Right Cover Leg Panel (2 pcs)



P7 - Left Cover Leg Panel (2 pcs)



P8 - Leg Panel Support Block (4 pcs)

NOTE: Packed with Hardware Kit



P9 - Leg Leveler (4 pcs)

PARTS REQUIRED:


12 pcs - **H1** Hex Bolt 2 pcs - **P2** Right Leg 12 pcs - **H2** Flat Washer 2 pcs - **P3** Left Leg 1 pc - **P1** Hockey Table Cabinet 1 pc - **T1** Wrench

STEP 1:

To assemble this table, leave P1 Hockey Table Cabinet face down in the carton lid.

Attach P2 Right Legs and P3 Left Legs using H1 Hex Bolts with H2 Flat Washers as shown in FIGURE 1.

Do not tighten H1 Bolts until completion of STEP 4.




PARTS REQUIRED:

8 pcs - **H3** Hex Bolt 8 pcs - **H5** Barrel Nut 2 pcs - **P6** Right Cover Leg Panel 1 pc - **T1** Wrench

8 pcs - H4 Flat Washer 2 pcs - P4 End Leg Panel 2 pcs - P7 Left Cover Leg Panel


STEP 2:

Attach **P4** End Leg Panels between two legs of **P2** Right Legs and **P3** Left Legs using **H3** Hex Bolts with **H4** Flat Washers and **H5** Barrel Nuts as shown in **FIGURE 2**. Use **T1** Wrench to tighten all bolts. **Important Note: Tighten, but do not over tighten H3 Bolts.**



STEP 3:

Carefully bow and slide P6 Right Leg Panel and P7 Left Leg Panel into the grooves of each leg assembly as shown in FIGURE 3.




PARTS REQUIRED:

8 pcs - **H6** Hex Bolt 4 pcs - **H7** Screw 4 pcs - **P8** Leg Panel Support Block 1 pc - **T1** Wrench

8 pcs - H4 Flat Washer 2 pcs - P5 Side Leg Panel 4 pcs - P9 Leg Leveler

STEP 4:


Attach P5 Side Leg Panels between P2 Right Legs and P3 Left Legs using H6 Hex Bolts with H4 Flat Washers as shown in FIGURE 4. Use T1 Wrench to tighten all bolts. Remember to tighten all H1 Leg Bolts from STEP 1.



STEP 5:


Attach **P8** Leg Panel Support Blocks to bottom of Leg assembly using pre-drilled pilot hole with **H7** Screws as shown in **FIGURE 5**. **Tighten, but do not strip out H7 screws.**

Thread P9 Leg Levelers into the Leg assembly as shown in FIGURE 5.



STEP 6:

Peel the backing off A3 Felt Pad and attach to A1 Striker as shown in FIGURE 6.



Congratulations! You have now assembled your HJ SCOTT Hockey Table. Please note the instructions below to ensure many years of trouble free use of your HJ SCOTT Hockey Table.

CARE AND USE OF YOUR HJ SCOTT HOCKEY TABLE

- 1. Use only a suitable 120v AC household outlet, and insure the cord is not a trip hazard.
- 2. Spray furniture polish is recommended to both protect the play field and increase the puck speed. Apply and wipe off with the air motor on.
- 3. Use a carpenters level to properly level table using the leg levelers.
- 4. This product is intended for **INDOOR** use only.
- 5. **DO NOT** operate the motor if the cord is damaged in any way.
- 6. **DO NOT** sit, climb or lean on the table.
- 7. **DO NOT** drag the table when moving it. This will damage the legs.
- 8. **DO NOT** set drinks on the table.
- 9. It is suggested that this table be placed close to a wall thus allowing the air motor cord to **NOT** be a trip hazard. Always turn air motor off when table is **NOT** in use.

Suggestion:

- The purchase of a 8 ft Pool Table cover will both protect and help keep table clean while table is not in use.
- See Page 10 about ordering information of additional strikers and pucks.

ELECTRONIC SCORER OPERATION:


- 1. Plug the power cord from the ON/OFF switch into a wall outlet.
- 2. Press the red ON/OFF switch on end apron to turn the air motor on.
- 3. This game includes a new touch panel control box with familiar icons to control the electronic scorer. Each icon is discribed below.
 - (1) = Power ON/OFF Press this button to turn the electronic scorer ON or OFF.
 - Sound ON/OFF Press this button while the game is on to turn the sound ON or OFF.
 - > = Start / Reset Press this button to begin the game. Press this button at end of game to reset back to the same game option.
 - \parallel = Time Press this button to select time options 15 minutes, 10 minutes, 5 minutes or "No Time Limit".


NOTE: If no score has been made or the button is not pressed for 15 minutes, the scoreboard will automatically turn off. However we suggest turning the power off when the game will not be used for an extended period of time.

HOCKEY GAME RULES:

- 1. This game is designed to be played with two (2) players, one at each end, or with four (4) players, two at each end of the game table. See Page 10 about ordering information of additional strikers and pucks.
- 2. Flip a coin to determine who will begin play, or a face-off can be held at the center of the table.
- 3. Play begins when the puck is placed on the playing surface. Players must hit the puck with the strikers and attempt to shoot into the opponent's goal.
- 4. One point is awarded when a puck is shot into the opponent's goal.
- 5. Winning the game: the winning score is accomplished by being the first player to reach a predetermined score or by being the player to score the most points within a given period of time.

ELECTRICAL CONNECTIONS & SPARE PARTS DRAWINGS





PRODUCT PARTS LIST FOR MODEL # HJAR8

Key #	Part #	Description	Qty.
H1	HJAR8WJH1	8mm x 57mm Hex Bolt	12
H2	HJAR8WJH2	8mm x 19mm Flat Washer	12
H3	HJAR8WJH3	6mm x 50mm Hex Bolt	8
H4	HJAR8WJH4	6mm x 19mm Flat Washer	16
H5	HJAR8WJH5	Barrel Nut	8
H6	HJAR8WJH6	6mm x 25mm Hex Bolt	8
H7	HJAR8WJH7	3mm x 15mm Phillips Washer Head Screw	4
T1	HJAR8WJT1	Wrench	1
A1	HJAR8WJA1	Striker	2
A2	HJAR8WJA2	Puck	2
A3	HJAR8WJA3	Felt Pad	2
P1	HJAR8WJP1	Hockey Table Cabinet (no blower motor)	1
P2	HJAR8WJP2	Right Leg	2
P3	HJAR8WJP3	Left Leg	2
P4	HJAR8WJP4	End Leg Panel	2
P5	HJAR8WJP5	Side Leg Panel	2
P6	HJAR8WJP6	Right Cover Leg Panel	2
P7	HJAR8WJP7	Left Cover Leg Panel	2
P8	HJAR8WJP8	Leg Panel Support Block	4
P9	HJAR8WJP9	Leg Leveler	4
C1R	HJAR8WJC1R	Main Electronic Unit with Control Panel	1
C3S	HJAR8WJC3S	LED Scorer with Short Wire	1
C3L	HJAR8WJC3L	LED Scorer with Long Wire	1
C4S	HJAR8WJC4S	Scoring Sensors with Short Wire	1
C4L	HJAR8WJC4L	Scoring Sensors with Long Wire	1
C5	HJAR8WJC5	Adapter	1
C6	HJAR8WJC6	ON/OFF Switch	1
C7	HJAR8WJC7	Blower Motor	1
C8	HJAR8WJC8	Puck Return Tray	2
K1	HJAR8WJK1	Hardware Kit	1
M1	HJAR8WJM1	Owner's Manual (New Version)	1

^{**} Additional **A1** Strikers and **A2** Pucks are available for purchase by calling or e-mailing Escalade Sports.

90 DAY LIMITED WARRANTY

This consumer warranty extends to the original consumer purchase of any AIR HOCKEY TABLE BY HJSCOTT Product (hereinafter referred as the "Product").

WARRANTY DURATION: This Product is warranted to the original consumer purchase of a period of 90 days from the original purchase.

WARRANTY COVERAGE: CUE&CASE warrants to the original Consumer Purchaser that any Product of its manufacture is free from defects in material and workmanship when used for the intended purpose under normal use and conditions. THIS WARRANTY IS VOID IF THE PRODUCT HAS BEEN DAMAGED BY ACCIDENT, UNREASONABLE USE, NEGLIGENCE, IMPROPER SERVICE, FAILURE TO FOLLOW INSTRUCTIONS PROVIDED WITH THE PRODUCT OR OTHER CAUSES NOT ARISING OUT OF DEFECTS IN MATERIAL AND WORKMANSHIP.

WARRANTY PERFORMANCE: During the above 90 days warranty period CUE&CASE shall repair or replace with a comparable model, and Product, or component thereof, which may prove defective under normal use and proper care, and which our examination shall disclose to our satisfaction to be thus defective, please contact our Warranty Dept.

1 (800) 835-7665 / Warranty Department

Or write us at:

Cue&Case Warranty Department
190 Cumberland Park Drive, St. Augustine, FL 32095

E-mail: customerexperience@hj-scott.com

Other than shipping requirements no charge will be made for such repair or replacement of inwarranty Products.CUE&CASE strongly recommends that the Product is insured for value prior to mailing.

WARRANTY DISCLAIMERS: ANY IMPLIED WARRANTIES ARISING OUT OF THIS SALE, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE ABOVE 90 DAY PERIOD. CUE&CASE SHALL NOT BE LIABLE FOR LOSS OF USE OF THE PRODUCT OR OTHER CONSEQUENTIAL OR INCIDENTAL COSTS, EXPENSES OR DAMAGES INCURRED BY THE CONSUMER OF ANY OTHER USE.

Some states do not allow the exclusion or limitation of implied warranties or consequential or incidental damages, so the above limitations or exclusions may not apply to you.

LEGAL REMEDIES: This warranty gives you specific legal rights and you may also have other rights which may vary from state to state.